




















SPARE PART LIST

ITEM No.	DESCRIPTIONS	PHOTO	ITEM No.	DESCRIPTIONS	PHOTO
11024	Main Board		540015	M5 Locknut CCW (7075 ALU) 4pcs	
18027	LED Board		530029	Battery Pad (2mm)	
520022	1/3 SONY Super HAD II CCD, PAL, 600TVL Camera, 2.5mm Lens		530039	GoPro Camera protector	
530036	5.8G Antenna		510029	Carbon fiber arm (4.0mm Carbon fiber) 2pcs	
520019	Motor CCW/CW (2305-2600kv)		510035	Main board protector (1.5mm Carbon fiber)	
540023	Aluminum standoff (5mm M3*28) 2pcs		510030	Main board bottom (2.5mm Carbon fiber)	
540024	Aluminum standoff (5mm M3*6) 4pcs		510031	Camera mount bottom (2.0mm Carbon fiber)	
530034	Tri-blade propeller 5040 (2pair) red		510032	Side camera mount (2.0mm Carbon fiber) 2pcs	
530037	Camera strap (20*250mm) 2pcs		510033	Camera mount top plant (1.5mm Carbon fiber)	
530038	Battery strap (25*200mm) 2pcs		510034	Batter protector (1.5mm Carbon fiber)	